

PICNIC TABLE MOUNTING KIT INSTRUCTIONS

MATERIALS LIST

- 4 - #4TBCK-05750 5 ¾" Angled Brackets
- 8 - #7HDWR-14225 ¼ x 2 ¼" Bolts
- 16 - #7HDWR-K8125 1 ¼" Screws
- 16 - #7HDWR-14WSH ¼" Flat Washers
- 8 - #7HDWR-14NUT ¼" Nylock Nuts
- 1 – Mounting Instructions

TOOLS NEEDED

- Drill with ¼" Bit and #2
Phillips Bit
- 2 – 7/16" Wrenches or Sockets

MOUNTING INSTRUCTIONS

Place assembled Picnic Table in desired location. Slide a bracket under each leg of picnic table. With 1 ¼" Screws fasten brackets to deck (if mounting on concrete use concrete fasteners, not included). With picnic table setting on brackets, use the ¼" drill bit to drill holes through legs, using the predrilled holes in brackets as your guide. Fasten picnic table to brackets using 2 ¼" bolts, washers and nylock nuts.

If mounting an existing table or if end caps have already been applied to table legs, carefully pry end caps off with straight blade screwdriver.

**If you encounter missing or defective parts, please contact manufacturer direct at
toll free # below.**